

Summary of common AT Commands for US Robotics 56K modems, 1a.pdf

Non-AT modem commands commands...

1. (any key) Aborts dialing process
2. +++ Escapes to on-line command mode (AT O0 = return to on-line mode)
3. A/ Re-execute last AT command (used for re-dialing)
4. Ctrl + C Abort the display of a help screen
5. Ctrl + S Stop/resume display of help screens

AT modem commands for modem setup...

1. AT \$ Display - AT command list
2. AT &\$ Display - Ampersand command set
3. AT D\$ Display - List of dial commands like: * # T P R , / ; W @ !
4. AT I3 Display - Modem type
5. AT I4 Display - Current modem settings (Example display of default hardware flow template: AT &F1 I4)
6. AT I5 Display - NVRAM settings for templates Y0 and Y1
7. AT I6 Display - Link diagnostics (chars sent & received)
8. AT **&F1** Load the **hardware flow control** template
9. AT &U0 Floor connect speed - Disabled
10. AT **&U1** Floor connect speed - **300 bps**
11. AT &U2 Floor connect speed - 1200 bps
12. AT &U3 Floor connect speed - 2400 bps
13. AT &N0 Ceiling connect speed = Variable
14. AT &N1 Ceiling connect speed = 300 bps
15. AT &N2 Ceiling connect speed = 1200 bps
16. AT **&N3** Ceiling connect speed = **2400 bps**

S-Register commands for modem setup...

S11=55 Milliseconds duration and spacing for DTMF dialing tones (default is 70 ms)

AT modem commands for testing modem connections...

1. AT **DT 480-2299** Dial a phone number using tone dialing
2. AT H0 On-hook (hang-up)
3. AT H1 Off-hook (listen to audio on the line)
4. AT M2 Speaker always on (default = M1 = speaker ON until CONNECT)
5. AT &T1 Initiate analog loopback test (cancel test with AT &T0)
6. AT &M0 Disable error control

AT commands for modem initialization string....

1. AT Y2 Power-on boot config: Generic template (&F0) as per defaults shown in manual
2. AT **Y3** Power-on boot config: Hardware flow control (&F1) Use dip switches: UUDU DUUD (1234 5678)
3. AT Y4 Power-on boot config: Software flow control (&F2) Use dip switches: DUDU DUDD
4. AT **&C1** Normal CD operation (default hardware flow value is CD override)

Misc additional AT commands...

- AT V0 Display numeric result codes
AT V1 Display verbal response codes
AT &A0 Result codes disabled
AT &A1 Result codes enabled
AT &A3 Result codes include LAPM/MNP/NONE/MNP5 protocol indicators

ASCII

^M = CR
^J = LF
^Q = Xon
^S = Xoff